


1260 Industrial Road, West Kelowna, B.C., Canada V1Z 1G5 Phone: (250) 769-6344 Fax: (250) 769-6303 info@alpineaerotech.com



# FLOOR BOARD, KIT, LHS INSTALLATION INSTRUCTIONS

# MODELS: BELL 205, 212, 412, 412CF & 412EP

Read all of the installation instructions thoroughly prior to the installation of this product



# Weight & Balance

<u>Part Number</u>	<u>Description</u>
AAL-212-020-017	Floor Board, Kit, LHS

<u>Weight</u>	Long. Arm	<u>Lat. Arm</u>
5.58*	146.87	30.19 LBL
2.53 (Kg)	3.73 (m)	0.77 (m) LBL

\* Total increase in weight to aircraft.

## **General Notes**

- 1. All Installation Instructions must be completed in accordance with standard aircraft practices. Refer to the current revision of the FAA manual AC 43.13, Aircraft Inspection, Repair & Alterations, for instructions.
- 2. All Hardware must be torqued to standard aircraft specifications. Refer to the current revision of the FAA manual AC 43.13, Aircraft Inspection, Repair & Alterations, for instructions.
- 3. All Dimensions are in imperial measures (inches/pounds).
- 4. Refer to the Floor Board, Kit, LHS Illustrated Parts Breakdown for the part numbers of the items contained within this document.
- 5. Refer to the Floor Board, Kit, LHS Maintenance Manual Supplement for he inspection and maintenance of the items contained within this document.

## Installation Notes




Cutouts may be added as required. If cutouts are added, Weight & Balance must be recalculated accordingly.



1. Temporarily remove the 2 Man, LHS, outboard facing seat/seat legs and any other fixed or loose items the may obstruct the installation of the Floor Board Assy, Item 1. Reference Figure 1.

# NOTE: Removal of the Stanchion Post assy may not be required.





- 2. Install the Floor Board Assy, Item 1, as shown. Reference Figure 2.
- 3. Remove and discard the existing floor panel hardware, 7 places, from the locations shown. Reference Figure 2.






Figure 2



- 4. Install the Clip Details, Item 5, and mounting hardware in the existing hardware locations. Reference Figure 3 & 4.
- Install the Retainer Details, Item 3, and mounting hardware in the existing hardware 5. locations. Reference Figure 3 & 5.









#### Grip Tape Install

- 6. Placement of the Grip Tape, is optional. Its location is approximate and can be placed to suite the individual operators needs. See Figure 6.
- 7. Trimming may be required to clear the existing floor cutouts.




Figure 6

8. Ensure that adequate pressure is applied to promote a good bond between the grip tape and panel assy. <u>NOTE:</u> The tape will go from a milky to a more translucent appearance once it has bonded properly.



- 9. Re-install the 2 Man, LHS, outboard facing seat/seat legs and any fixed or loose items previously removed. Reference Step 1.
- 10. Installation complete.
- 11. Perform a general inspection of all items to ensure proper installation.
- 12. Update the aircraft log book for the installation of the Floor Board, Kit, LHS.