

# FLOOR BOARD, KIT, FWD INSTALLATION INSTRUCTIONS

MODELS: BELL 205, 212, 412, 412CF & 412EP

Read all of the installation instructions thoroughly prior to the installation of this product

Revision: C

Date: 2021-05-07 Doc. No.: AAL-212-025-019 Page 1 of 8





### Weight & Balance

| <u>Part Number</u> | <u>Description</u>    | <u>Weight</u> | Long. Arm | <u>Lat. Arm</u> |
|--------------------|-----------------------|---------------|-----------|-----------------|
| AAL-212-020-019    | Floor Board, Kit, FWD | 23.07*        | 100.26    | 0.03 LBL        |
|                    |                       | 10.46 (Ka)    | 2.55(m)   | 0.00 (m) LBL    |

<sup>\*</sup> Total increase in weight to aircraft.

#### **General Notes**

- 1. All Installation Instructions must be completed in accordance with standard aircraft practices. Refer to the current revision of the FAA manual AC 43.13, Aircraft Inspection, Repair & Alterations, for instructions.
- 2. All Hardware must be torqued to standard aircraft specifications. Refer to the current revision of the FAA manual AC 43.13, Aircraft Inspection, Repair & Alterations, for instructions.
- 3. All Dimensions are in imperial measures (inches/pounds).
- 4. Refer to the Floor Board, Kit, FWD Illustrated Parts Breakdown for the part numbers of the items contained within this document.
- 5. Refer to the Floor Board, Kit, FWD Maintenance Manual Supplement for the inspection and maintenance of the items contained within this document.

#### **Installation Notes**



Cutouts may be added as required. If cutouts are added, Weight & Balance must be recalculated accordingly.

Revision: C

Date: 2021-05-07 Doc. No.: AAL-212-025-019 Page 2 of 8






### **Installation Instructions**

1. Temporarily remove the 4 Man, AFT facing seat and 5 Man, FWD facing seats/seat legs and any other fixed or loose items they may obstruct the installation of the Floor Board Assy, Item 1. Reference Figure 1.

NOTE: Removal of the Stanchion Post assys may not be required.



Revision: C


Date: 2021-05-07 Doc. No.: AAL-212-025-019 Page 3 of 8





### **Installation Instructions**

- 2. Install the Floor Board Assy, Item 1, as shown. Reference Figure 2.
- 3. Remove and discard the existing floor panel hardware, 14 places, from the locations shown. Reference Figure 2.



Revision: C


Date: 2021-05-07 Doc. No.: AAL-212-025-019 Page 4 of 8





### **Installation Instructions**

- 4. For 212, 412 applicability, install the Clip Detail, Items 7 thru 11 and mounting hardware in the existing hardware locations. Figure 3 & 4.
- 5. For 205 applicability, install the Clip Detail, Items 9, 10, 12, 13 &14 and mounting hardware in the existing hardware locations. Clip Details, Items 12, 13 & 14 have no fastener holes, temporarily place the clips in their respective locations, pick existing fastener locations and transfer the holes to the clips. Reference Figures & 4.
- 6. Install the Retainer Detail, Item 5, and mounting hardware in the existing hardware locations. Reference Figure 3 & 5.



Revision: C

Date: 2021-05-07 Doc. No.: AAL-212-025-019 Page 5 of 8





TYPICAL CLIP DETAIL INSTALLATION SHOWN

## **Installation Instructions**





Figure 4



Revision: C

Date: 2021-05-07 Doc. No.: AAL-212-025-019 Page 6 of 8





#### **Installation Instructions**

#### **Grip Tape Install**

- 7. Placement of the Grip Tape is optional. It's location is approximate and can be placed to suite the individual operators needs. See Figure 6.
- 8. Trimming may be required to clear the existing floor cutouts.




Figure 6
Some Cutouts
Shown

9. Ensure that adequate pressure is applied to promote a good bond between the grip tape and panel assy. <u>NOTE:</u> The tape will go from a milky to a more translucent appearance once it has bonded proplerly.

Revision: C

Date: 2021-05-07 Doc. No.: AAL-212-025-019 Page 7 of 8





## **Installation Instructions**

- 10. Re-install the 4 Man, AFT facing seat and 5 Man, FWD facing seats/seat legs and any fixed or loose items previously removed. Reference Step 1.
- 11. Installation complete.
- 12. Perform a general inspection of all items to ensure proper installation.
- 13. Update the aircraft log book for the installation of the Floor Board, Kit, FWD.

Revision: C

Date: 2021-05-07 Doc. No.: AAL-212-025-019 Page 8 of 8